



fig. 2



KY 466

S	1,2,3,4,9,10,14,12,27,32,13,14,15,22,16,17,18,19,20,21,	23,24,30,31,32,29,	5,6,7,8,	25,26,	28
C	3,1,4,6,51,13,2,8,17,5,11,14,9,52,12,10,18,19,26,20,23,22,21,25,24,15,16,55,30,27,28,31,43,49,48,50,40,29,56,42,37,54,44,45,38,47,46,7,33,39,34,41,53,35				
R	4,37,5	6,9,36,10,11,15,33,8,13,38,11,7,31,32,39,	42,43,2,3,34,41,16,17,40,22,23,28,29,27,26	19,24,25,44,30,21,20,	18,1

S -	1, 5, 2, 3, 4, 6, 7, 8, 9, 10, 12, 13, 11, 14, 15, 32	16, 17, 18, 19, 20, 21, 22, 23, 24	25, 26, 27	31, 28, 30, 29
R -	42, 43, 1, 2, 3, 4, 5, 6, 8, 36, 9, 10, 38, 39, 35, 33, 12, 17, 41, 30, 41, 13, 44, 15, 16, 34, 20, 21, 40, 22, 23, 45, 18, 19, 27, 26, 25, 28, 29, 24, 32, 44			
C -	1, 51, 2, 57, 3, 4, 5, 6, 5, 6, 44, 45, 7, 9, 8, 13, 47, 46, 11, 12, 49, 10, 52, 44, 43, 55, 15, 16, 17, 21, 22, 24, 26, 25, 10, 19, 27, 23, 20, 48, 28, 30, 29, 31, 32, 54, 34, 36, 33, 41, 38, 37, 39, 40, 42, 53			






Fig. 1


GOLFSCHAKELAAR - KORT - MIDDEN - LANG - GETEEKEND IN STAND "KORT"  
 PICK-UP SCHAKELAAR : GETEKEND IN STAND "GRAMOFON"

S	1, 2, 3, 4, 9, 10, 11, 12, 27, 32, 13, 14, 15, 22, 16, 17, 18, 19, 20, 21,	23, 24, 30, 31, 32, 29	5, 6, 7, 8,	25, 26	28
C	3, 1, 4, 6, 51, 13, 2, 8, 17, 5, 11, 14, 9, 52, 12, 10, 18, 19, 26, 20, 23, 22, 21, 25, 24, 15, 16, 55, 30, 27, 28, 31, 43, 49, 48, 50,	40, 29, 56, 42, 37, 54, 44, 45, 38, 47, 46, 7, 33, 39, 34, 41, 53,			
R	4, 37, 5, 35, 12	6, 9, 36, 10, 14, 15, 33, 8, 13, 30, 11, 7, 31, 32, 39,	42, 43, 2, 3, 34, 41, 16, 17, 40, 22, 23, 28, 29, 27, 26,	49, 24, 25, 44, 50, 21, 20, 45, 18, 1,	

fig. 3



KY 466





Spanningen tot 50V ±10%, met Voltmeter 50V bij 1000 Ω/V  
 Spanningen van 50-500V ±10% met Voltmeter 500V bij 1000 Ω/V voor de app. vanaf Nr 6001

fig 3a

Volt	170	80	90	125	2	70	60	220	205	47	39	260	245	-10	220	Volt												
S	1,2,3,4, 9,10	22	32	16	17,18,19,20,21	11,12	13,14,15	30,31	31a,							S												
C	40, 113, 51,3	57, 4,5,6	11,12,26	52,18	19,10, 20,22	25,23, 21	24,14,9,15	16,55	30	27,28,	48	43,44,9	56,29	42, 53, 50,	37	54,38,46,47	44,45	33, 7, 39	34	31								
R	4	37	35	12	5,	6,	10,	15,8a	8b,42	23	32	22	31	19	44,24,	16	40	34	20,29,	27	26	14	15,	21	30,	20,	1	18

ERRES

KY 466







fig 2a

voor de app. vanaf Nr 6001



S	1, 2, 3, 4, 9, 10, 22, 32, 16, 17, 18, 19, 20, 21, 11, 12, 13, 14, 15, 30, 31, 31a,	29,	25, 26,	28
C	40, 1, 13, 51, 3, 57, 4, 5, 6, 11, 12, 26, 52, 18, 19, 10, 20, 22, 25, 23, 21, 24, 14, 9, 15, 16, 55, 30, 27, 28,	48, 43, 49, 56, 29, 42, 53,	50,	37, 54, 38, 46, 47, 44, 45, 33, 7, 39, 34,
R	4, 37, 35, 12, 5, 6, 10,	45, 8a, 8b, 42,	23, 32, 22, 31, 19, 44, 24, 16, 40, 34,	28, 29, 27, 26, 14, 13, 21, 30, 20, 1, 18

ERRRES

KY 466

S -	1, 5, 2, 3, 4, 6, 7, 8, 9, 10, 12, 13, 11,	14, 15, 32	16, 17, 18, 19, 20, 21, 22, 23, 24,	25, 26, 27,	31, 28, 30, 29
R -	42, 43, 1, 2, 3, 1, 3, 4,	7, 5,	6, 8, 36, 9, 10,	3, 9, 3, 9, 3, 5, 3, 3, 12, 17, 41,	30, 4, 13, 44, 45, 46, 34, 20, 21, 40, 22, 23, 45, 18, 19, 27, 26, 25, 28, 29, 24, 32, 44
C -	1, 51, 2, 57, 3, 4, 5, 6, 5, 6, 44,	45, 7, 9, 8, 13, 47, 46, 11, 12, 49, 10, 52, 44,	43, 55, 15, 16, 17,	21, 22, 24, 26, 25, 40, 49, 27, 23, 20, 48, 28, 30, 29, 31, 32, 54, 34, 36, 33, 47, 38, 37, 39,	40, 42, 53
					50





Fig: 1a

voor de app. vanaf Nr 6001

GOLFSCHAKELAAR - KORT - MIDDEN - LANG - GETEEKEND IN STAND "KORT"  
 PICK-UP SCHAKELAAR : GETEEKEND IN STAND "GRAMOFON"




fig 3b

voor de app. vanaf Nr 6001

Spanningen tot 50V, ± 10% met Voltmeter 50V bij 1000Ω/V

Volt		-5		-25		29		17		8		2		Volt	
S	5, 6, 7, 8	44, 45, 41, 46, 47	2, 41, 33, 7, 41, 17, 39	17	8	2	S	5, 6, 7, 8	44, 45, 41, 46, 47	2, 41, 33, 7, 41, 17, 39	17	8	2	S	
C		45, 25, 43, 3					C		45, 25, 43, 3					C	
R	18						R	18						R	

ERRRES KY 466