


FIG. 1



N	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55
C	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55

GOLPERRENSCHAKKELAAR GETEKEND IN STAND NORMAAL
 BASSSCHAKKELAAR GETEKEND IN STAND NORMAAL
 ANTENNESCHAKKELAAR GETEKEND IN STAND BUITENANTENNE (K)

WAFERANGE - SWITCH DRAWN IN POSITION F.M.
 SELECTIVITY - SWITCH 3 POSITIONS, 1 SMALL, 2 NORMAL, 3 BROAD (P)
 AERIAL SWITCH DRAWN IN POSITION OUTDOOR AERIAL (K)

ANSLUITPLAAT M.F. CONNECTION M.F.
 B1 ECC81
 B2 ECH81
 B3 EBF80
 B4 EBF80
 B5 EABC80
 B6 EL 84
 B7 EM34
 B8 EZ 80

