



GOLFEREKSCHAKELBAAR IN STAND FM  
 COMMUTEUR DE GAMMES D'ONDES DANS LA POS. FM  
 WELLENBEREICHSSCHALTER IN STAND FM




ERRES RA 665

DE SPANNINGEN ZIJN GEMETEN T. O. V. J.  
 LES TENSIONS SONT MESUREES ENVERS J.  
 DIE SPANNINGEN SIND GEMESSEN GEGEN J.



C	31	88	35	32	34	4	101	38	39	5	7	8	18	41	2	12	10	42	11	45	43	13	14	28	51	86	52	98	97	85	57	58	80	67	65	81	68	94	63	70	71	72	73	93	75	74	84	59	78	82	76	83	50	54	53	34	36	37	40	42	43	44	38																																							
R	18	47	12	13	14	60	1	13	3	2	14	3	4	15	5	6	7	16	15	16	17	21	20	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100
S	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100		



C	101	2	76	91	86	80	95	40	43	70	44	48	89	72	58	94	57	63	69	68	73	33	34	35	75	83	79	77	78	84			
	101a	2a	31	88	97	81	39	38	82	32	40	41	67	71	56	45	53	58	94	64	57	63	69	68	73	93	74	55	83	79	77	78	84
R	50				13	14	40	16	39	15	23	22	42	51	36	37	26	33	35	34	28	29	30	43	48	45	47	44	52	60	53	54	38